

Hydrant Meter Use Agreement

Rental Procedures

- Use of meter is for outside water usage
- Must be first year landscaping
- Must have acceptable access to hydrant (either north or south towers only)
- Only one hose connection available from meter

Deposits Required:	\$ 500.00	¾" Meter
	1000.00	2 ½" Meter
	25.00	Wrench (required)

Service Charge:	\$ 25.00	per month
-----------------	----------	-----------

Bulk Water Rate:	\$ 9.40	per 1000 gallons
------------------	---------	------------------

Installation Instructions

1. Install meter on small fire hydrant nozzle and tighten all remaining nozzles.
2. **VERY IMPORTANT** Slowly open fire hydrant completely with wrench provided (do not use regular pipe wrench).
3. Slowly open hydrant meter allowing air to escape.
4. When watering is completed, always shut meter off and remove hosing first.
5. Slowly turn fire hydrant off, one turn at a time.
6. Remove hydrant meter from hydrant.
7. Reinstall hydrant cap.